

Sample Submission for Flow Cytometry

Please follow the parameters below for bringing materials for flow cytometry.

1. Label each sample tube with description of sample including dilution or concentration.
2. Make sure each tube is sealed with cap and paraffin and then wrap sample tubes in protective packaging (e.g. bubble wrap).
3. Place 2 Refrigerant Bricks in appropriate temperature-controlled shipping container.
4. Add sample tubes to container.
5. Seal box and send via overnight shipping to:
Cytometry Research, LLC
11175-A Flintkote Avenue
San Diego, CA 92121
6. Fax or email a completed Service Form with the shipper's tracking number to:
(858) 642-1989 fax • service@CytometryRes.com

Thank you for your attention to this information. We appreciate your business and look forward to working with you.